



Markins Tripod Base Installation



1. Remove ballhead



2. Unscrew hook, and loosen column fastener and remove the center column assembly



3. Remove center column fastener and bush (liner)



4. Assemble TB; leave 8mm of bolt out, and hollow side of bolt goes inside



6. Screw in TB unit and tighten it up



7. Screw in hook into the tube and tighten it up



7. Tripod and base is ready



8. With Markins Q-Ball and tripod base